

Nikon

COOLPIX S610c

Wireless LAN Connection Guide



How to Use my **Picturetown**

EUR **En**

Table of Contents

| | |
|--|------------|
| Notices | iii |
| About the Wireless LAN Connection Guide | 1 |
| Important Information and Precautions..... | 2 |
| The Wireless LAN Features and my Picturertown..... | 4 |
| my Picturertown..... | 4 |
| Picture Mail | 5 |
| Picture Bank..... | 5 |
| my Picturertown Setup Workflow..... | 6 |
| First Steps | 8 |
| Confirming Wireless LAN Connection Requirements | 8 |
| Ready Information Required for Wireless LAN Connection..... | 9 |
| Network Profile..... | 9 |
| my Picturertown User Information..... | 11 |
| Picture Mail Recipients | 12 |
| Protecting the Camera with a Password..... | 12 |
| Configuring the Camera's Wireless Settings | 13 |
| Wireless Settings Using the Utility | 13 |
| 1 Installing the Utility | 13 |
| 2 Starting the Utility | 15 |
| 3 Configuring a Network Profile | 17 |
| 4 Entering my Picturertown User Information..... | 20 |
| 5 Specifying Picture Mail Recipients/Recipient Groups | 22 |
| 6 Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera) | 23 |
| 7 Finishing Wireless Settings | 25 |

| | |
|---|-----------|
| Wireless Settings from the Camera | 26 |
| Basic Operation of the Wireless Settings..... | 26 |
|  1 Configuring a Network Profile | 28 |
|  2 Entering my Pictown User Information..... | 33 |
|  3 Specifying Picture Mail Recipients/Recipient Groups | 34 |
|  4 Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera) | 37 |
| Configuring a Network Profile for a Home Wireless LAN Using WPS..... | 39 |
| <hr/> | |
| Registering with my Pictown | 41 |
| Registering a Camera with my Pictown | 43 |
| <hr/> | |
| Uploading Pictures to the my Pictown Server | 44 |
| Sending Picture Mail | 44 |
| Using Picture Bank | 46 |
| Uploading All Pictures at Once | 46 |
| Uploading Selected Pictures..... | 47 |
| Connecting to a Wireless LAN..... | 49 |
| <hr/> | |
| Viewing Pictures on the my Pictown Server | 51 |
| <hr/> | |
| Appendix | 52 |
| Error Messages..... | 52 |
| Troubleshooting | 53 |
| Index..... | 55 |



Notices

This product, which contains encryption software developed in the United States, is controlled by the United States Export Administration Regulations and may not be exported or re-exported to any country to which the United States embargoes goods. As of April 2007 the following countries were subject to embargo: Cuba, Iran, North Korea, Sudan, and Syria.

Restrictions on Wireless Devices

The wireless transceiver included in this product conforms to wireless regulations in the country of sale and is not for use in other countries (products purchased in the EU or EFTA can be used anywhere within the EU and EFTA). Nikon does not accept liability for use in other countries. Users who are unsure as to the original country of sale should consult with their local Nikon service center or Nikon-authorized service representative. This restriction applies to wireless operation only and not to any other use of the product.

Notice for customers in the U.S.A. and Canada

Federal Communications Commission (FCC) and Industry of Canada (IC)

Declaration of Conformity

This device complies with Part 15 of FCC rules and RSS-Gen of IC rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

FCC/IC RF Exposure Statement

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research. Wireless LAN Module (GC-131) has been tested and found to comply with FCC/IC radiation exposure limits set forth for an uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. Please refer to the SAR test report that was uploaded at FCC website.

This device should not be co-located or operated in conjunction with any other antenna or transmitter.

Notice for customers in Europe

Hereby, Nikon, declares that this digital camera is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Notice for customers in France

Outdoor use of the wireless transceiver is prohibited in France.

Public Wireless LAN

Public wireless LAN connection is available only by Wayport in the United States, by T-Mobile hotspots in the United States, by Orange in France, by TeliaSonera in Sweden, by SingTel in Singapore, by PCCW in Hong Kong, by KT in Korea, and by Q-Ware in Taiwan. When configuring network profiles for a public wireless LAN hotspot, use the following SSIDs, displayed in the camera monitor with SSID detection:

- Wayport: **Wayport_Access**
- T-Mobile: **tmobile**
- Orange: **Orange**
- TeliaSonera: **homerun**
- SingTel: **Wireless@SG**
- PCCW: **PCCW**
- KT: **NESPOT**
- Q-Ware: **wifly**

Operation of the COOLPIX S610c wireless LAN features is only guaranteed and supported with connection via the wireless service providers listed above, and only within the borders of the country, or countries, in which service is provided by a particular provider.

About the Wireless LAN Connection Guide

This guide explains the wireless LAN features built into the COOLPIX S610c to help you enjoy my Picturetown using the wireless LAN features. Read this guide thoroughly before use, and keep it where all those who use the camera will read it.

See the *Quick Start Guide* and the *User's Manual* for information on shooting and playing back pictures.

Symbols and Conventions

To make it easier to find the information you need, the following symbols and conventions are used:



This icon marks cautions, information that should be read before use to prevent damage to the camera.



This icon marks tips, additional information that may be helpful when using the camera.



This icon marks notes, information that should be read before using the camera.



This icon indicates that more information is available elsewhere in this guide.

Notations

- A Secure Digital (SD) memory card is referred to as a "memory card."
- The setting at the time of purchase is referred to as the "default setting."
- The names of menu items displayed in the camera monitor, and the names of buttons or messages displayed in a computer monitor are indicated in bold text.

Illustrations and Screen Display

Illustrations shown in this guide may differ from actual display.

Before Using Wireless LAN Communication Features

Be sure to read the sections, "Notices" ( iii) and "Important Information and Precautions" ( 2), in this guide. See also page 133 of the *COOLPIX S610/S610c User's Manual* for more information on wireless transfer specifications.



Important Information and Precautions

Note the following important points before using this product's wireless LAN features.

Restrictions of Use Under Radio Laws and Precautions when Using Radio Transmissions

- The wireless transceiver included in this product conforms to wireless regulations in the country of sale and is not for use in other countries (products purchased in the EU or EFTA can be used anywhere within the EU and EFTA).
- When using the wireless LAN features of this product, the product will search for wireless networks automatically. At this time, the product may display wireless networks (SSID) for which you are not an authorized user. Use of such wireless networks may be regarded as unauthorized access. Never connect to an SSID that you are not authorized to use.
- Always keep in mind that radio transmission or reception of data is subject to interception by third parties.

Personal Information Management and Disclaimer

- User information registered and configured with the product, including wireless LAN connection settings and other personal information, is susceptible to alteration and loss resulting from operational error, static electricity, accident, malfunction, repair or other handling. Always keep separate copies of important information. Nikon is not responsible for any direct or indirect damages or lost profits resulting from alteration or loss of content that is not attributable to Nikon.
- Before discarding this product or transferring it to another owner, it is recommended that you apply the **Reset** option from the **Wireless settings** item in the camera's setup menu, to delete all user information registered and configured with the product, including wireless LAN connection settings and other personal information.
- Nikon is not responsible for any communication charges stemming from unauthorized access to a public wireless LAN by third parties, or any other damages resulting from theft of the product.
- Nikon is not responsible for any damages stemming from unauthorized use of e-mail addresses stored in the camera resulting from theft of the product.

Precautions and Limitations when Using the Wireless LAN Features

- Connection to a public wireless LAN, using the wireless LAN features of the COOLPIX S610c to access the wireless services (hereinafter referred to as Services) supported by this camera, is guaranteed only in specified countries. Use of these Services over a public wireless LAN requires subscription to services offered by a specific provider in each country. See "Public Wireless LAN" (iv) for more information on countries in

- which public wireless LANs can be accessed by, and the wireless service providers that support connection of, this camera. Nikon is not responsible for any direct or indirect damages or lost profits resulting from any connection made at your own risk.
- Connection may not be possible if the public wireless LAN's operation standards or specifications are modified.
 - Be sure to specify the e-mail addresses of Picture Mail recipients correctly. Errors will not be indicated if the e-mail address is incorrect, nor will error notification be sent to your e-mail address.
 - Access to Picture Mail Web pages, indicated with links in Picture Mail e-mail notification messages, is not restricted. Web pages can be viewed by anyone who may obtain Picture Mail URLs.
 - Nikon makes no guarantees whatsoever concerning the ability of these Services to store or safeguard images. Be sure to maintain separate back-up copies of all important images. Nikon is not responsible for any direct or indirect damages or lost profits resulting from alteration or loss of content that is not attributable to Nikon.
 - Your use of the Services is completely at your own risk and Nikon accepts no responsibility on your behalf.
 - By using the Services, you agree not to upload, post, e-mail or otherwise transmit or communicate any material through the Services that is obscene, pornographic, unlawful, threatening, an invasion of any privacy or publicity rights of any party, defamatory, libelous, illegal or otherwise objectionable, or infringes on any copyright, trademark or other intellectual property or contractual right of any party.
 - You hereby irrevocably and unconditionally waive, discharge and release Nikon, its affiliates and subsidiaries, and their respective officers, directors, employees, agents, legal representatives, and successors ("Nikon Parties") from and against any and all claims by or against you related to any material you post, e-mail or otherwise transmit or communicate through the Services.
 - Furthermore, you agree to indemnify, defend, and hold harmless the Nikon Parties from and against any claims, damages, liabilities, costs and expenses (including reasonable attorneys' and professionals' fees and litigation costs) related to any material you post, e-mail or otherwise transmit or communicate through the Services.
 - You understand that (i) your right to use the Services may be terminated by Nikon and/or (ii) the materials you post, e-mail or otherwise transmit or communicate through the Services may be deleted or removed by Nikon in the event you breach the foregoing, or any other terms and conditions that Nikon may require in connection with your use of the Services.
 - These Services are subject to change, suspension, or termination without notice.
 - Be sure to read Nikon's "Privacy Management Policy" located at the following URL: <http://www.nikon.co.jp/main/eng/privacy/index.htm>
 - If you are in Europe, click on your country of residence at the following URL and follow the link <privacy policy>: <http://www.europe-nikon.com/support/>
 - You can visit the my Picturetown Web site at the following URL: <http://mypicturetown.com/>



The Wireless LAN Features and my Picturetown

The wireless LAN communication features built into the COOLPIX S610c can be used to upload pictures from the camera to the my Picturetown server over the Internet. Use the Picture Mail service to share pictures with family and friends, and the Picture Bank service to store pictures to dedicated space on the server. Connection to a wireless LAN access point is required.

my Picturetown

my Picturetown is an Internet service for storing and viewing photos. The service offers up to 2 GB of free storage.

- Pictures can be stored on the server using the wireless LAN features of the COOLPIX S610c, or a computer connected to the Internet.
- Pictures stored on the server can be easily managed and sorted using a computer.

Access my Picturetown from the following URL:

<http://mypicturetown.com/>


COOLPIX S610c Wireless LAN Communication Features

Wireless LAN communication features cannot be used to connect the COOLPIX S610c to a computer.

Picture Mail

Pictures and recipients are selected and uploaded to the my Picturetown server using the camera. E-mail notification is automatically sent to selected recipients, allowing these family and friends to view your pictures. Uploaded pictures can be viewed by accessing the Web page specified in the e-mail notification from a computer. This feature provides you with a convenient way to share pictures, such as those from vacations or that record your children's growth.


Movie and sound files cannot be uploaded.



Picture Bank

Pictures and movies are uploaded to the my Picturetown server for storage. The my Picturetown server can be used as your own personal storage space for pictures, and those pictures can be downloaded to a computer any time. Upload of selected pictures can be initiated, or picture upload can be set to begin automatically when the AC adapter is connected to the camera to charge the battery, making this a convenient service when taking a large number of pictures or for saving the pictures you take on an everyday basis.

Sound files cannot be uploaded.



my Pictown Setup Workflow

Before taking advantage of my Pictown services using the wireless LAN features of the COOLPIX S610c, the camera's wireless settings must be configured and you must register with my Pictown. These two processes are generally referred to as "setup." The camera's wireless settings can be configured using a computer and the my Pictown Utility (supplied), or by using just the camera. Follow either of the procedures described below.

Applying wireless settings using the my Pictown Utility

Applying wireless settings using the camera

First Steps (be sure that all wireless LAN requirements are in place and ready necessary information) (8)
Confirm network requirements for wireless LAN connection, and ready the necessary network profile for wireless LAN connection and user information for my Pictown.

Wireless settings

Configuring a Network Profile (17)

Configure the network profile necessary for connecting the camera to the Internet via an access point.

Configuring a Network Profile (28)

Configure the network profile necessary for connecting the camera to the Internet via an access point. Configuring the network profile is simple using WPS (7, 39).

Enter my Pictown User Information (20)

Enter the information, such as your e-mail address, required to use the my Pictown services. Once this information has been specified, e-mail notification requesting user registration with my Pictown will be sent to this e-mail address.

Enter my Pictown User Information (33)

Enter the information, such as your e-mail address, required to use the my Pictown services, from the camera's **Sender** option.

Specifying Picture Mail Recipients/Recipient Groups (22)*

Specifying Picture Mail Recipients/Recipient Groups (34)*

Protecting Wireless LAN Information Stored in the Camera (23)*

Apply password protection to the camera's wireless LAN features.

Protecting Wireless LAN Information Stored in the Camera (37)*

Apply password protection to the camera's wireless LAN features.

Uploading Pictures to the my Pictown Server (44)

Upload pictures using Picture Mail or Picture Bank. Once pictures have been uploaded, e-mail notification requesting user registration with my Pictown will be sent to the e-mail address specified from the camera's **Sender** option.

Registering with my Pictown (41)

Use a computer to open the e-mail notification requesting user registration, click the URL provided in the e-mail notification, and register the camera and user information with my Pictown from the sign-up Web page. Setup is complete when you receive an e-mail message confirming my Pictown registration.

* Picture Mail recipients and the camera's password do not need to be specified immediately.



The my Picturetown Utility

- The my Picturetown Utility (hereafter “Utility”) is software that can be installed on a computer and used to configure the camera’s wireless settings, and to request user registration with my Picturetown when the camera is connected to a computer via the supplied USB cable. The Utility is convenient for entering a large amount of text.
- The Utility is installed from the Software Suite CD supplied with the camera (📄 13).



Wi-Fi Protected Setup (WPS)

- Wi-Fi Protected Setup is a standard that simplifies home connection and security of wireless devices.
- The COOLPIX S610c supports WPS. If your wireless LAN access point also supports WPS, configuring the network connection between your home wireless LAN access point and the camera is simple. (See the documentation provided with your access point to confirm whether or not WPS is supported.)
See “Configuring a Network Profile for a Home Wireless LAN Using WPS” (📄 39) for detailed information about using WPS to configure a network profile. Note that WPS cannot be used to configure a network profile for a public wireless LAN access point.

Confirming Wireless LAN Connection Requirements

One of the following conditions must be met in order to use the wireless LAN connection features.

Home wireless LAN

Home wireless LAN refers to a wireless LAN that utilizes a wireless LAN access point at home.

A home wireless LAN that offers connection via an access point (infrastructure mode) is required.

my Picturetown is not available if the home wireless LAN uses a proxy server to connect to the Internet.

For more information on home wireless LAN configuration, contact the manufacturer of the access point, or see other commercially available information on wireless LANs.

Public wireless LAN

Public wireless LAN refers to wireless LAN that utilizes a public wireless Internet access point, such as those available in coffee shops, hotels, and airports.

See “Public Wireless LAN” (8 iv) for more information on countries in which public wireless LANs can be accessed by, and the wireless service providers that support connection of, this camera.

Ready Information Required for Wireless LAN Connection

Network Profile

Retrieve settings for the wireless LAN network to which the camera will be connected. This information is necessary when setting up the camera's network profile (🔗 17, 28). (There is no need to ready this information when using WPS to configure network profiles.)

- When connecting via a home wireless LAN, retrieve the wireless LAN network settings from the network profile for a computer connected to the wireless LAN access point. For information on displaying the network profile, see the documentation provided with the wireless LAN access point, or contact the manufacturer of the device.
- When connecting via a public wireless LAN, retrieve the wireless LAN network settings from information provided by the wireless service provider to which you subscribe (🔗 iv).

SSID (network name)

This is the name of the wireless LAN network to which the access point belongs. The SSID is comprised of up to 32 alphanumeric characters.

Authentication

All data are encrypted to protect against interception by third parties. The same type of encryption (authentication method) must be specified for both the wireless LAN access point and the camera.

Select an authentication method from **Open system**, **Shared key**, **WPA-PSK**, or **WPA2-PSK**.

Encryption

This is the type of encryption for the method selected for **Authentication**.

The type of encryption available differs depending upon the authentication method.

| Authentication method | Type of encryption available to the camera |
|-----------------------|--|
| Open system | None or WEP |
| Shared key | WEP |
| WPA-PSK | TKIP* |
| WPA2-PSK | AES* |

* When configuring the camera's wireless settings from the camera's setup menu, both **TKIP** and **AES** are available for **WPA-PSK** or **WPA2-PSK**.

Encryption key

This is the encryption key for the specified type of **Authentication** and **Encryption**. An encryption key is not required when **Authentication** is set to **Open system** and **Encryption** is set to **None**.

Key index

When **Encryption** is set to **WEP**, select a key index, which is the setting for the WEP key. The camera's default setting is **1**. If selecting a key index other than **1**, use the Utility to specify a setting suited to the wireless LAN access point (🔗 17). Specification of the a key index is not required when **Encryption** is set to **None**, **TKIP**, or **AES**.

IP address (home wireless LAN only)

This is a unique identifier assigned to communication devices on a computer network. The IP address can be acquired automatically with this camera. If the network uses a fixed IP address, manually enter the camera's IP address, as well as the subnet mask, gateway, primary DNS, and secondary DNS.


User name/Password (public wireless LAN only)

The user name and password provided by the wireless service provider to which you subscribe may be necessary when configuring the camera's network profile or connecting to the network.

When MAC Address Filtering Disables Home Wireless LAN Access

If your access point's SSID is not set to "any" (to allow connection of any wireless device), or if MAC address filtering (a unique identifier attached to each device on a LAN) is enabled, use a computer to modify access point settings to allow connection of any wireless device and register the camera's MAC address with the access point beforehand. Follow the procedure below to confirm the camera's MAC address.



- 1 Press the **MODE** button in playback mode or shooting mode. Use the rotary multi selector to choose  and press the **OK** button.



The setup menu is displayed.

For information on using the rotary multi selector, see "Basic Menu Operation" (26).

- 2 Use the rotary multi selector to choose **Firmware version** and press the **OK** button.



MAC address

my Pictown User Information

The following information is required to register user information and the camera (📷 20, 33, 41) with my Pictown, and to log-in to my Pictown (📷 51) after picture upload.

E-mail address

You must register a computer e-mail address with my Pictown. Specify an e-mail address, comprised of up to 64 recognized e-mail characters. Mobile telephone e-mail addresses are not supported.

- E-mail notification requesting user registration with my Pictown will be sent to this e-mail address.
- Once registered, use this e-mail address for the Email ID when logging in to my Pictown. This e-mail address is also used to identify you as the sender in e-mail notification sent to recipients with picture upload using Picture Mail.

Alias

Specify an alias, comprised of up to 16 alphanumerical characters, to use with my Pictown.

The alias is also used to identify you as the sender in e-mail notification sent to recipients with picture upload using Picture Mail.

Password

Use this password when logging in to my Pictown from a computer. Specify a password, comprised of four to ten alphanumerical characters.

Key information

Key information refers to unique information attached to each camera.

- If using the Utility to configure wireless settings, you need not enter key information.
- If using the camera to configure wireless settings, enter key information in the my Pictown user registration page after uploading pictures for the first time.
- See "Registering with my Pictown" (📷 41) for details on retrieving key information.

Picture Mail Recipients (Required Only for Picture Mail)

The following information is required to upload pictures using Picture Mail.

E-mail address

Recipient's e-mail address is comprised of up to 64 recognized e-mail characters. Up to 30 recipients can be specified with the camera. Mobile telephone e-mail addresses are not supported.

Alias

Specify recipient's alias, comprised of up to 16 alphanumerical characters.

Group

Recipients can be grouped for specification of multiple recipients as a single Picture Mail recipient. Specify a name for the recipient group, comprised of up to 16 alphanumerical characters.

See "5 Specifying Picture Mail Recipients/Recipient Groups" (22) or "3 Specifying Picture Mail Recipients/Recipient Groups" (34) for more information.

Protecting the Camera with a Password

A password (four-digit number) can be applied to prevent unauthorized access to the camera's wireless services by third parties, and to protect information stored in the camera.

See "6 Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera)" (23) or "4 Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera)" (37) for more information.

Configuring the Camera's Wireless Settings

Wireless Settings Using the Utility

The camera's wireless settings can be configured from a computer using the Utility (my Picturetown Utility).

my Picturetown Utility System Requirements

Windows

Compatible operating systems: 32-bit Windows Vista Service Pack 1 (Home Basic/Home Premium/Business/Enterprise/Ultimate editions), Windows XP Service Pack 3 (Home Edition/Professional)

Macintosh

Compatible operating systems: Mac OS X (version 10.3.9, 10.4.11, 10.5.3)

Refer to the Nikon Web site for the latest information on operating system compatibility.

Notes on Software Installation

- Exit all other applications and turn off any virus-checking software.
- Log on to an account with administrator privileges.
- The illustrations in this section are from Windows Vista.



1

Installing the Utility

Install the Utility on a computer.

When configuring the network profile for a home wireless LAN ( 17), using a computer connected to the home wireless LAN, at a location where the home wireless LAN can be accessed, is recommended.

1 Turn on the computer and insert the Software Suite CD into the CD-ROM drive.

Windows:

Choose **Run Welcome.exe** in the AutoPlay dialog to start the Install Center program. If your computer is running Windows XP, the Install Center program will start. Proceed to step 3.

Macintosh:

The **Software Suite** folder will open automatically. Double-click the **Welcome** icon. If the folder does not open automatically, double-click on the **Software Suite** CD icon on the desktop.

If the Install Center program Does not Start Automatically (Windows only)

Open the Software Suite by selecting **Computer** from the **Start** menu (Windows Vista), or **My Computer** from the **Start** menu (Windows XP), and double-clicking the **Software Suite** CD icon.

2 Enter the computer's administrator name and password (Macintosh only).

Enter the computer's administrator name and password, and then click **OK**.

3 Confirm the language and click **Next**.

If Nikon Transfer Is Already Installed

The Language Selection dialog will not be displayed if Nikon Transfer is installed. The Install Center window is displayed in the language selected when Nikon Transfer was first installed.

4 Click **Custom Install**.



5 Select **my Picturetown Utility** (✓) and click **Install**.

The my Picturetown Utility installer will start.

Follow the on-screen instructions to complete the installation.



6 Finish the installation.

Click **Finish** (Windows) or **Quit** (Macintosh) and follow the on-screen instructions to exit the Install Center program.



7 Remove the Software Suite CD from the CD-ROM drive.

This completes installation.

Uninstalling the Utility

Windows: Select **Start>All Programs>my Picturetown Utility>my Picturetown Utility Uninstall** and follow the on-screen instructions to complete uninstallation.


Macintosh: Open **Applications>Nikon Software>my Picturetown Utility**, double-click the **my Picturetown Utility Uninstaller** icon, and follow the on-screen instructions to complete uninstallation.

2 Starting the Utility

1 Turn off the camera.


If the camera's battery is exhausted while configuring wireless settings, the settings will not be applied correctly. Use a fully charged battery to prevent the camera from turning off unexpectedly.

2 Connect the camera to the computer using the supplied USB cable.



3 Turn on the camera.

If Nikon Transfer starts automatically, exit Nikon Transfer before proceeding.



4 Start the Utility.

Follow the instructions below to start the Utility:

Windows: Start the computer and select **Start>All Programs>my Picturetown Utility> my Picturetown Utility**.

Macintosh: Start the computer and open **Applications>Nikon Software>my Picturetown Utility** folder, and double-click the **my Picturetown Utility** icon.

When the Utility finishes loading, the screen shown at right will be displayed. Take note of suggestions given and click **Next**.


You can also start the Utility by clicking the **my Picturetown Utility** icon (📎) on the desktop (Windows) or the **my Picturetown Utility** icon (📎) in the Dock (Macintosh).



✓ Connecting the USB Cable

- When connecting the USB cable, be sure that the connectors are oriented correctly. Do not use force when connecting the USB cable. When disconnecting the USB cable, do not pull the connector at an angle.
- Connection may not be recognized when the camera is connected to a computer via a USB hub.

5 The Select Action dialog is displayed.



- ① **Add Network Profiles**
- ② **Edit/Delete Network Profiles**
- ③ **Change password**
- ④ **Reset camera**
- ⑤ **Edit address book**
- ⑥ **Register to my Picturetown**

- ① Configure wireless LAN settings information with the camera (📖 17).
- ② Edit or delete network profiles stored in the camera (📖 19).
- ③ Apply, edit or delete the camera's password (📖 23).
- ④ Reset all wireless settings stored in the camera (📖 24).
- ⑤ Enter Picture Mail recipient aliases and e-mail addresses, or create groups of Picture Mail recipients (📖 22).
- ⑥ Enter the information required for my Picturetown registration and send the information to my Picturetown (📖 20). Connection to the Internet is required.

3

Configuring a Network Profile

Enable connection of the camera to the Internet via a wireless LAN access point. Use the Utility to apply the same network settings used by the wireless LAN network to the camera. Up to ten network profiles to connect can be registered.

1 Choose **Add Network Profiles** from the Select Action dialog (16) and click **Next**.

Click **Cancel** to cancel configuration.



2 Choose the type of network profile and click **Next**.

If configuring a home wireless LAN profile, choose **Add Network Profile at Home Wireless LAN**. If configuring a public wireless LAN profile, choose **Add Network Profile at Public Wireless LAN**.

See "Public Wireless LAN" (iv) for more information on countries in which public wireless LANs can be accessed by, and the wireless service providers that support connection of, this camera.

- Windows:

If **Add Network Profile at Home Wireless LAN** is selected, proceed to step 3.

If **Add Network Profile at Public Wireless LAN** is selected, proceed to step 4.

- Macintosh:

Proceed to step 4.



3 Choose a setup option and click **Next**.

If **Automatic setup (recommended)** is selected and the desired SSID is displayed in the **Network name (SSID)** (9) field*, select the SSID and enter the encryption key in the **Encryption key** (9) field. Click **Next** to apply the setting. The network profile is stored in the camera. Proceed to step 7.

* SSIDs registered with the computer's wireless LAN settings are displayed.

If connection by any wireless device is not allowed by the access point, or the desired SSID is not detected, select **Manual setup (for advanced users)** to specify the IP address manually, or to configure wireless settings using a computer that is not connected to the Internet, and click **Next**. Proceed to step 4.



4 Configure **Network name (SSID)** (🔑 9), **Authentication** (🔑 9), and **Encryption** (🔑 9), and click **Next**.

Enter the encryption key for the selected authentication method in the **Encryption key** (🔑 9) field and select a **Key index** (🔑 9) option.

- If **Open System** was selected for **Authentication** and **WEP** was selected for **Encryption**, or **Shared Key** was selected for **Authentication**, enter the encryption key in the **Encryption key** field and select a **Key index** option.
- If **WPA-PSK** or **WPA2-PSK** was selected for **Authentication**, enter the encryption key in the **Encryption key** field.

If **Open System** was selected for **Authentication**, and **None** was selected for **Encryption**, make no other changes and click **Next**.

If **Add Network Profile at Home Wireless LAN** was selected in step 2, proceed to step 5. If **Add Network Profile at Public Wireless LAN** was selected in step 2, proceed to step 6.



5 Choose **Auto** configuration or **Manual** configuration, and click **Next**.

To acquire the IP address automatically, choose **Auto**. When **Next** is clicked, the settings are applied and the network profile is stored in the camera. Proceed to step 7.

To specify a fixed IP address, choose **Manual**, enter the appropriate information in the **IP Address**, **Subnet Mask**, **Gateway**, **Primary DNS**, and **Secondary DNS** (🔑 10) fields, and click **Next** to apply the settings. The network profile is stored in the camera. Proceed to step 7.



6 Enter a **Username** and **Password** (🔑 10) provided by the wireless service provider to which you subscribe (🔑 iv), and click **Next**.

The settings are applied and the network profile is stored in the camera. Proceed to step 7.



7 An Action completed successfully dialog will be displayed.

When setting up the wireless LAN features of the camera for the first time, choose **Yes, register now** and click **Next**.

Proceed to “ 4 Entering my Picturetown User Information” ( 20).

When **No, register later** is selected and **Next** is clicked, an Action completed successfully dialog, with options for finishing or performing another action, will be displayed. To apply additional settings, choose **Select another action to perform**,

and click **Next**. The monitor will return to the Select Action dialog ( 16). To register user information with my Picturetown after additional settings are applied, choose **Register to my Picturetown** in the Select Action dialog and proceed to “ 4 Entering my Picturetown User Information” ( 20).

If user information and the camera have already been registered with my Picturetown, the dialog shown at right will not be displayed. The Action completed successfully dialog, with options for finishing or performing another action, will be displayed instead. To apply additional settings, choose **Select another action to perform** in the Action completed successfully dialog, and click **Next**. The monitor will return to the Select Action dialog ( 16).



Configuring Multiple Network Profiles

To configure more than one network profile, repeat the procedures described from step 1 ( 17) for each wireless LAN.

Network profiles can also be configured using the camera ( 28).

Editing/Deleting Network Profiles

Follow the procedures described below to delete or edit a network profile stored in the camera.

1 Choose **Edit/Delete Network Profiles** from the Select Action dialog ( 16) and click **Next**.

2 Choose the desired SSID.

Click **Edit...** to display the screen displayed in step 4 of “ 3 Configuring a Network Profile” ( 18). Repeat steps 4 through 6 to edit the network profile.

Click **Delete...** to delete the selected SSID.



3 Click **Next**.

Proceed to “ 7 Finishing Wireless Settings” ( 25).



4 Entering my Pictoretown User Information

Store the information required for my Pictoretown user registration with the camera and send it to my Pictoretown. This information is necessary to log-in to my Pictoretown after picture upload. The e-mail address and alias are automatically stored in the camera's **Sender** setting (🔗 33), and are used to identify you as the sender in e-mail notification sent to recipients with picture upload using Picture Mail.

- Connection to the Internet is required.

1 Choose **I will create my Pictoretown account** and enter the appropriate information in the **E-Mail Address** (🔗 11), **Password** (🔗 11), **Confirm Password**, and **Nick Name** (🔗 11) fields.

Enter an e-mail address comprised of up to 64 recognized e-mail characters, a password comprised of four to ten alphanumerical characters, and a nickname (alias) comprised of up to 16 alphanumerical characters. Enter the same password in the **Confirm Password** field as that entered in the **Password** field.

Mobile telephone e-mail addresses are not supported.

No error message, or indication that an error has occurred, is sent from the server when delivery errors occur due to incorrect entry of e-mail addresses. Be sure that your e-mail address has been entered correctly.

If you have already registered with my Pictoretown, choose **I already have my account**, and enter the information already registered in the **E-Mail Address** and **Password** fields (🔗 43).

The dialog shown above is also displayed when **Register to my Pictoretown** is selected from the Select Action dialog (🔗 16), and **Next** is clicked. If the camera has been protected with a password (🔗 23, 37), enter the password.

Once all information has been entered, click **Next**.



2 Check that the information is correct and click **Next**.

The Action completed successfully dialog, with options for finishing or performing another action, will be displayed, and the e-mail address and nickname will be stored in the camera. The specified user information and the camera's key information will be sent to the my Picturetown server over the Internet.

E-mail notification requesting user registration with my Picturetown will be sent to the e-mail address configured with the camera. Follow the instructions in the e-mail notification to continue registration. See "Registering with my Picturetown" (📧 41) for more information.

If you have already registered with my Picturetown, an e-mail message confirming my Picturetown registration will be sent to the specified e-mail address.



Once you have registered with my Picturetown, proceed as indicated below.

- **Using Picture Mail:** Choose **Select another action to perform** and click **Next** to return to the Select Action dialog. Proceed to "📧 5 Specifying Picture Mail Recipients/Recipient Groups" (📧 22).
- **Not using Picture Mail:** Choose **Select another action to perform** and click **Next** to return to the Select Action dialog. Proceed to "🔒 6 Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera)" (🔒 23).
- **Completing wireless settings:** Proceed to "🔚 7 Finishing Wireless Settings" (🔚 25).

✓ Sending User Information

When sending the information required for my Picturetown user information to my Picturetown from the Utility, the computer which uses a proxy server can be used. However, some proxy settings may not allow the information to be sent to my Picturetown.

✎ Editing the my Picturetown User Information

When uploading pictures using Picture Mail or Picture Bank after user information has been registered with my Picturetown, user information (including information stored in the camera's **Sender** setting) stored in the camera cannot be displayed or edited using the camera or the Utility (🔒 42). In addition, the my Picturetown password cannot be changed using the camera or the Utility.

Once recipients and recipients group have been specified, proceed as indicated below.

- **Applying a password to the camera:** Choose **Select another action to perform** and click **Next** to return to the Select Action dialog. Proceed to “ 6 Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera)” ( 23).
- **Completing wireless settings:** Proceed to “ 7 Finishing Wireless Settings” ( 25).



Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera)

A password ( 12) can be applied to prevent access to wireless LAN information stored in the camera, including network profiles and recipient e-mail addresses, by third parties if the camera should be lost or stolen, or otherwise compromised. In addition, all camera settings can be restored to their default settings and data stored in the camera's internal memory can be deleted before the camera is transferred to another owner or discarded.

Applying a Password to the Camera

Applying a password to the camera to protect wireless LAN information is recommended.

- 1 Choose **Change password** from the Select Action dialog ( 16) and click **Next**.

Click **Cancel** to cancel configuration.



- 2 Choose **Change password** and enter the same password (four-digit number) in the **Enter new password** and the **Confirm password** fields.

If changing the password, also enter the current password in the **Enter old password** field.

When **Next** is clicked, the Action completed successfully dialog, with options for finishing or performing another action, is displayed and the password is applied to the camera. Proceed to “ 7 Finishing Wireless Settings” ( 25).



Entering a Password

If the camera is protected with a password, the password entry screen is displayed when configuring the camera's wireless settings or uploading pictures using the wireless LAN features. Enter the camera's password to proceed.

Choosing a Password

Avoid using a password that can be easily guessed, such as a birth date. Be sure that you do not forget the password.

Removing Password Protection

Choose **Remove password** in step 2 and enter the current password in the **Enter old password** field. Click **Next** to remove the password.

Resetting the Camera

Follow the instructions below to reset all wireless LAN connection settings, including the password, stored in the camera. Use this option to delete all user information stored in the camera before transferring it to another owner. This option can also be used to reset the camera if you forget the password.

1 Choose **Reset camera** from the Select Action dialog (16) and click **Next**.

Click **Cancel** to cancel configuration.



2 Check **Reset camera** and click **Next**.

The camera is reset.



Once the camera is reset, the dialog shown in step 7 of “ 3 Configuring a Network Profile” ( 19) will be displayed. Repeat “ 4 Entering my Pictoretown User Information” ( 20) procedures to enter user information, unless the camera was reset prior to transferring ownership.



Finishing Wireless Settings

Once the camera's wireless settings have been configured, finish the Utility.

1 Finish the Utility.

Choose **Finish wizard** and click **Next**.



2 Disconnect the camera from the computer.

Turn off the camera before disconnecting the USB cable.

You must register with my Pictoretown to complete the setup. See “Registering with my Pictoretown” ( 41) for more information.

Wireless Settings from the Camera


This section explains wireless LAN setup using the camera.

Basic Operation of the Wireless Settings

Displaying the Wireless Settings Menu


- 1 Press the **MODE** button in playback mode or shooting mode. Rotate the rotary multi selector to choose  and press the **OK** button.

The setup menu is displayed.





- 2 Rotate the rotary multi selector, or press up or down, to choose **Wireless settings** and press the **OK** button.

The wireless settings menu is displayed.



Basic Menu Operation

Use the rotary multi selector to choose menu items and apply selections.



¹ Items can also be selected by pressing the rotary multi selector up or down.

² Pressing right advances display to the next screen.

Note on the Rotary Multi Selector

Since the rotary multi selector can be used in various ways, concrete descriptions are included only in cases where necessary.

In this guide, up, down, left, and right presses of the rotary multi selector are indicated with ▲, ▼, ◀, and ▶.

Entering Text with the Camera

Text for information such as aliases, e-mail addresses, and WEP keys can be entered using the camera's rotary multi selector. Rotate the rotary multi selector, or press ▲, ▼, ◀, or ▶, to choose a character or , , , or  in the keyboard area.



Text entry area

Selected characters are displayed here.

Keyboard area

Use the rotary multi selector to highlight characters and press the  button to select.




- Text is entered at the current cursor position in the text entry area.
- Highlight  or  and press the  button to move the cursor in the text entry area.
- Highlight  and press the  button to change the type of character entered. Each time the  button is pressed, the type of character changes in the following order: lowercase letters → uppercase letters → symbols → lowercase letters. The type of characters displayed in the keyboard area can also be changed by pressing and holding the rotary multi selector ▲ or ▼, or by continuously rotating it right or left. The position of the scroll bar at left in the monitor display indicates the type of characters currently shown.
- To delete a character, move the cursor to that character's position and press the  button to delete.
- Press the **T**  button to preview the characters that have been entered. Press the **T**  button again to return to the text entry screen.
- Once all text necessary has been entered, highlight  and press the  button. The monitor display proceeds to the next screen.



1 Configuring a Network Profile

Enable connection of the camera to the Internet via a wireless LAN access point. Follow the procedures indicated below to apply the same network settings used by the wireless LAN network to the camera. See "Configuring a Network Profile from the Camera" (🔗 29) for more information.



* See "Public Wireless LAN" (🔗 iv) for more information on countries in which public wireless LANs can be accessed by, and the wireless service providers that support connection of, this

If your wireless LAN access point supports WPS, configuring the network profile for a home wireless LAN access point is simple (🔗 39).


More on Configuring Network Profiles

Network profiles for wireless LANs can be configured (🔗 29) after pictures and recipients have been selected under the following circumstances:


- The public wireless LAN access point does not utilize the IEEE 802.1X standard.
- Home wireless LAN access points are configured as follows:
 - The access point's SSID is set to "any" (to allow connection of any wireless device).
 - MAC address filtering is not enabled.
 - Data is encrypted using WEP encryption, or data encryption is not enabled.
 - IP addresses are acquired automatically (DHCP).

Configuring a Network Profile from the Camera


- 1 Choose **Network profile** from the **Wireless settings** option (F26) in the camera's setup menu and press the **OK** button.



- 2 Choose **Configure manually** and press the **OK** button.



The camera will search for available SSIDs and then the SSID selection screen will be displayed.



3 Choose the desired SSID (📶 9) and press the ⏹ button.


Up to ten SSIDs, with network profiles configured with the camera and those detected by the camera, are listed.

If connection by any wireless device is not allowed with an access point and the desired SSID is not detected, select **New** and press the ⏹ button. Enter a network name (SSID) (up to 32 alphanumeric characters) in the SSID screen.

For information on entering text, see "Entering Text with the Camera" (📖 27).

Choose an SSID with a network profile and press the ⏹ button. Profile settings can be edited by following the same procedure used for SSIDs for which network profiles have not been configured. To delete an existing SSID profile, select the SSID and press the 🗑 button.

Up to ten wireless LAN network profiles can be stored in the camera. If ten profiles have already been configured and you would like to add a new one, first use the camera or the Utility to delete an existing network profile from the camera.



📌 SSID Selection Screen

SSIDs with network profiles are listed first regardless of signal strength. The icon to the left of each SSID indicates signal strength and is displayed in red when out of range (📶 52, 53).


The icon to the right of each SSID shows the status of the camera's network profiles:

- 🏠 (home wireless LAN profile configured)
- (public wireless LAN profile configured)

See "Public Wireless LAN" (📖 iv) for more information on countries in which public wireless LANs can be accessed by, and the wireless service providers that support connection of, this camera.

- (no profile configured)

If the full network name cannot be displayed, highlight the SSID and press the **T** (🔍) button to display the full name. Press the **T** (🔍) button again to return to the select SSID screen.




4 Choose the network type and press the **OK** button.

If connecting via a home wireless LAN, choose **Home wireless LAN**.

If connecting via a public wireless LAN, choose **Public wireless LAN**. See "Public Wireless LAN" (iv) for more information on countries in which public wireless LANs can be accessed by, and the wireless service providers that support connection of, this camera.



If **New** was selected in step 3, proceed to step 5, or proceed to step 6 if the SSID detected by the camera was selected.



5 Choose the desired authentication method (9) and press the **OK** button.

When **Open system** is selected, choose **None** or **WEP** in the encryption screen and press the **OK** button.

- When **None** is selected, proceed to step 7 if **Home wireless LAN** was selected in step 4, or proceed to step 8 if **Public wireless LAN** was selected in step 4.
- When **WEP** is selected, proceed to step 6.



6 Enter the encryption key (9).

When a new SSID was added in step 3: The encryption key entry screen will vary depending upon the selected authentication method in step 5.

- If **Open system** was set to **WEP**, or **Shared key** was selected, enter the WEP key in the WEP key screen.
- If **WPA-PSK** or **WPA2-PSK** was selected, choose **TKIP** or **AES** in the encryption screen and enter the TKIP or AES key.

When an SSID detected by the camera was selected in step 3: The encryption key entry screen for the selected SSID is displayed.



For information on entering text, see "Entering Text with the Camera" (27).

If **Home wireless LAN** was selected in step 4, proceed to step 7, or proceed to step 8 if **Public wireless LAN** was selected.

7 Specify the camera's IP address (10).

To acquire the IP address automatically, choose **Auto** and press the **OK** button.

To enter a fixed IP address, choose **Manual** and press the **OK** button.



Specify the **IP address**, **Subnet mask**, **Gateway**, **Primary DNS**, and **Secondary DNS** settings (10).

When configuring **IP address**, **Subnet mask**, **Gateway**, **Primary DNS**, and **Secondary DNS** settings, enter each set of numbers so that they are aligned to the right. Numbers must be entered correctly for the settings to be properly applied.

For information on entering text, see "Entering Text with the Camera" (27).

Once all network settings have been configured, **Done** will be displayed and the monitor display will return to the wireless settings screen. If connecting via a home wireless LAN, network profile configuration is complete.

To connect to another wireless LAN access point, repeat the procedures described from step 1.





8 Enter user name and password (10).

Enter your user name in the user name screen and your password in the password screen. Your user name and password are provided by the wireless service provider to which you subscribe (iv).

For information on entering text, see "Entering Text with the Camera" (27).

Once all network settings have been configured, **Done** will be displayed and the monitor display will return to the wireless settings screen. If connecting via a public wireless LAN, network profile configuration is complete.

To connect to another wireless LAN access point, repeat the procedures described from step 1.



When setting up the wireless LAN features of the camera for the first time, next enter the information required for my Picturetown user registration. Proceed to "Entering my Picturetown User Information" (33).




Entering my Picturetown User Information

Enter the information required for user registration with my Picturetown from the **Sender** option. This information is necessary to log-in to my Picturetown after picture upload. The alias and e-mail address are used to identify you as the sender in e-mail notification sent to recipients with picture upload using Picture Mail.

If you have already registered with my Picturetown, use the same e-mail address and nickname (alias) currently used by my Picturetown (📷 43).

- 1 Select **Sender** from the **Wireless settings** option (📷 26) in the camera's setup menu, and press the **OK** button.




- 2 Enter your e-mail address (up to 64 recognized e-mail characters).

Mobile telephone e-mail addresses are not supported.

No error message, or indication that an error has occurred, is sent from the server when delivery errors occur due to incorrect entry of e-mail addresses. Be sure that your e-mail address has been entered correctly.

For information on entering text, see "Entering Text with the Camera" (📷 27).



- 3 Enter your alias (up to 16 alphanumerical characters).

Once the alias has been entered, the confirm address and alias screen will be displayed. Press the **OK** button to apply the settings and return to the wireless settings screen.



Once sender information has been configured, proceed as indicated below.

- **Using Picture Mail:** Proceed to "3 Specifying Picture Mail Recipients/Recipient Groups" (34).
- **Not using Picture Mail:** Proceed to "4 Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera)" (37).

Editing the my Picturetown User Information

When uploading pictures using Picture Mail or Picture Bank after user information has been registered with my Picturetown, user information (including information stored in the camera's **Sender** setting) stored in the camera cannot be displayed or edited using the camera or the Utility (42).


3 Specifying Picture Mail Recipients/Recipient Groups

Specifying Picture Mail Recipients

Follow the instructions below to specify a recipient (e-mail address and alias) for Picture Mail e-mail notification.

Recipients can also be added, or edited, later using the Utility or the camera. See "5 Specifying Picture Mail Recipients/Recipient Groups" (22) for more information on performing these actions using the Utility.

- 1 Select **Address options** from the **Wireless settings** option (26) in the camera's setup menu and press the **OK** button.




- 2 Select **New** and press the **OK** button.


If recipients or groups have been specified, they are listed under **New**.

The recipient's information can be edited by following the same procedure used for specifying a new recipient. Choose a recipient, press the **OK** button, and proceed to step 4.

To delete a specified recipient, highlight the recipient and press **DELETE**.



3 Select **Address** and press the **OK** button.




4 Enter recipient's e-mail address (12).

Enter an e-mail address comprised of up to 64 recognized e-mail characters.

Mobile telephone e-mail addresses are not supported.

For information on entering text, see "Entering Text with the Camera" (27).

Up to 30 recipients can be specified.



5 Enter recipient's alias (12).

Enter an alias comprised of up to 16 alphanumerical characters.

Once the alias has been entered, the confirm address and alias screen will be displayed. Press the **OK** button to apply the settings and return to the choose address screen. To add recipients, repeat step 2 through 5. To create recipient groups, see "Creating Recipient Groups" (36).



Once recipients have been specified, proceed to "4 Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera)" (37).

Creating Recipient Groups


Group (📷 12) containing multiple recipients can be created. This is useful when Picture Mail is often sent to the same group of recipients. If individual recipients (📷 34) have not been registered, register recipients before creating a recipient group.

- 1 Select **New** in the choose address screen shown in step 2 of "Specifying Picture Mail Recipients" (📷 34), and press the ⓧ button.

If recipients or groups have been specified, they are listed under **New**.


Group information can be edited by following the same procedure used for specifying a new group. Choose a group, press the ⓧ button, and proceed to step 3.

To delete a specified group, highlight the group and press the 🗑 button.



- 2 Select **Group** and press the ⓧ button.

Up to 5 groups can be created.



- 3 Enter the group's name.

Enter a name for the group, comprised of up to 16 alphanumerical characters.


For information on entering text, see "Entering Text with the Camera" (📷 27).



- 4 Select recipients for the group.

Rotate the rotary multi selector, or press ▲ or ▼, to highlight recipients by their alias (or e-mail address), and press ► to select the recipient (✓). Press ◀ to cancel the selection. Repeat this procedure to select additional recipients.

Press the ⓧ button to finalize recipient selection. **Done** will be displayed and the monitor display will return to the choose address screen.





Protecting Wireless LAN Information Stored in the Camera (Applying a Password/Resetting the Camera)


A password (🔑 12) can be applied to prevent access to wireless LAN information stored in the camera, including network profiles and recipient e-mail addresses, by third parties if the camera should be lost or stolen, or otherwise compromised. In addition, all camera settings can be restored to their default settings and data stored in the camera's internal memory can be deleted before the camera is transferred to another owner or discarded.

Applying a Password to the Camera

Applying a password to the camera to protect wireless LAN information is recommended.

- 1 Select **Password** from the **Wireless settings** option (🔑 26) in the camera's setup menu and press the **OK** button.

The password screen will be displayed.



- 2 Select **Set/change password** and press the **OK** button.



- 3 Specify a password for the camera, or edit the current password.

To protect the camera with a password, enter a password in the new password screen. The password should consist of four numbers.

To edit the password, enter the current password in the current password screen. When the new password screen is displayed, enter a new password.

When a password is entered, the re-enter password screen will be displayed for confirming the password. Enter the correct password again.

For information on entering text, see "Entering Text with the Camera" (🔑 27).

When the password has been re-entered, the message, **Password settings complete.** will be displayed and the monitor display will return to the wireless settings screen.



🔑 Entering a Password

If the camera is protected with a password, the password entry screen is displayed when configuring or utilizing the wireless LAN features. Enter the camera's password to proceed.

When setting up the wireless LAN features of the camera for the first time, the final step requires user registration with my Picturetown.

First, use Picture Mail (📧 44) or Picture Bank (📁 46, 47) to upload pictures to my Picturetown.


Once pictures have been uploaded, e-mail notification requesting user registration with my Picturetown will be sent to the e-mail address specified as instructed in “📧 Entering my Picturetown User Information” (📧 33). See “Registering with my Picturetown” (📧 41) for more information on user registration.

Resetting the Camera

Follow the instructions below to reset all wireless LAN connection settings, including the camera's password, stored in the camera. Use the **Reset** option to delete all user information stored in the camera before transferring it to another owner. This option can also be used to reset the camera if you forget the password.

- 1 Select **Reset** from the **Wireless settings** option (📶 26) in the camera's setup menu and press the **OK** button.


The confirmation dialog will be displayed.



- 2 Select **Yes** and press the **OK** button.

The message, **Wireless settings have been reset.** will be displayed and the monitor display will return to the wireless settings screen.

To cancel the reset operation, select **No** in the confirmation dialog and press the **OK** button.



🔪 Resetting the Camera and Camera Password

- Avoid using a password that can be easily guessed, such as a birth date. Be sure that you do not forget your password.
- To delete the current password without resetting the camera, select **Delete password** in step 2 of “Applying a Password to the Camera,” and press the **OK** button. Enter the password to be deleted in the current password screen, highlight **↔**, and then press the **OK** button.
- When the **Reset** option is applied, user information must be registered with my Picturetown again (📧 43).


Configuring a Network Profile for a Home Wireless LAN Using WPS

The network profile for a home wireless LAN can be easily configured if the wireless LAN access point supports WPS.


WPS supports two configuration methods: Push-Button Configuration (PBC) and Personal Identification Number (PIN) method.

Configuring a Network Profile Using the PBC Method

- 1 Choose **Network profile** from the **Wireless settings** option (26) in the camera's setup menu and press the **OK** button.





- 2 Select **Push-button WPS** and press the **OK** button.



- 3 Press the WPS button on the access point (wireless router), then press the **OK** button on the camera.

If the message, **Configuration failed**, is displayed, begin again from step 1. If configuration fails repeatedly, configure the network profile manually (28).




Configuring a Network Profile Using the PIN Method


- 1 Establish a cabled or wireless connection between the computer and access point, and open the access point's WPS configuration page on the computer.

For instructions on connecting the access point to a computer and displaying the configuration pages, see the documentation provided with the wireless LAN access point.

- 2 Choose **Network profile** from the **Wireless settings** option (F26) in the camera's setup menu and press the **OK** button.



- 3 Choose **PIN-code WPS** and press the **OK** button.




An eight-digit PIN will be displayed.



- 4 Enter the PIN displayed in the camera's monitor in the WPS configuration page's PIN field on the computer.

- 5 Press the **OK** button on the camera.

If the message, **Configuration failed**, is displayed, begin again from step 2. If configuration fails repeatedly, configure the network profile manually (F28).



When setting up the wireless LAN features of the camera for the first time, next enter the information required for my Picturetown user registration. See "Entering my Picturetown User Information" (F33).

Registering with my Pictown

Registration (creation of a user account) with my Pictown is required to take advantage of my Pictown services.

1 Use a computer to open the e-mail notification requesting user registration.



E-mail notification requesting user registration with my Pictown will be sent to the e-mail address specified for user information.

If my Pictown user information was configured using the Utility (☞ 20), e-mail notification requesting user registration with my Pictown will be sent after user information is sent to my Pictown. User information has been sent to my Pictown when the Action completed successfully dialog is displayed.

If my Pictown user information was configured using the camera (☞ 33), use Picture Mail (☞ 44) or Picture Bank (☞ 46, 47) to upload pictures to my Pictown once to receive e-mail notification requesting user registration with my Pictown.

2 Click the URL provided in the e-mail notification requesting user registration, and register with my Pictown from the sign-up Web page.

- The following information is required for user registration:
 - Nickname (the alias stored in the camera's **Sender** setting; ☞ 20, 33)
 - Email ID (the e-mail address stored in the camera's **Sender** setting; ☞ 20, 33)
 - Password for my Pictown (the password specified if user information was configured using the Utility; ☞ 20)
 - Key information* (not necessary if user information was configured using the Utility)
- * Confirm key information by selecting **Key information** from the **Wireless settings** option (☞ 26) in the camera's setup menu, and pressing the **OK** button.



- For more information, follow the instructions and procedures provided in e-mail messages received from my Pictown and the sign-up Web page.

3 Receive the e-mail message confirming my Pictown registration.

An e-mail message confirming my Pictown registration will be sent to the registered e-mail address.

This completed setup of the wireless LAN features.

Notes on User Registration

- Register user information as soon as possible to protect pictures, along with other personal information, from unsolicited viewing or theft. Until user information is registered, pictures are uploaded to temporary space on the server with no security measures applied.
- Until user information is registered, e-mail notification requesting user registration will be sent whenever pictures are uploaded. If you do not receive the e-mail notification, the information stored in the camera's **Sender** setting may be incorrect. Correct the information (🔧 33) and upload pictures again.
- When uploading pictures after user information has been registered with my Pictown, the user information (including information stored in the camera's **Sender** setting) stored in the camera cannot be displayed or edited from the camera or the Utility. In addition, the my Pictown password cannot be edited from the camera or the Utility. Use a computer's Web browser to access my Pictown to edit user information.
- Before discarding the camera or transferring it to another owner, confirm whether or not pictures have ever been uploaded using my Pictown services. If pictures have been uploaded, ever once, be sure that you have registered with my Pictown, and then reset all wireless settings (🔧 24, 38).
- If this camera was given to you by a previous owner, reset all wireless settings (🔧 24, 38) before using the camera and taking advantage of wireless services.

Note on Protecting Personal Information

Once the wireless LAN features have been used, personal information is stored in the camera and on the my Pictown server. To protect personal information from unsolicited viewing or theft, apply a password to protect data stored in the camera (🔧 23, 37), and register with my Pictown to protect uploaded data. It is highly recommended that these protection measures be applied.

Accessing the my Pictown Web site

You can visit the my Pictown Web site at the following URL:
<http://mypictown.com/>

Registering a Camera with my Picturetown

A camera must be registered with the my Picturetown server in any of the following situations:

- You registered with my Picturetown before setting up the wireless LAN features of this camera (e.g. this is a second camera).
- The camera is reset for any purpose other than transfer of ownership (🔧 24, 38).

Follow the procedures indicated below to register the camera.

1 Be sure that the network requirements for connecting the camera to a wireless LAN (🔧 8) have been met.

2 Configure the camera's network settings (🔧 17, 28).

3 Register my Picturetown user information with the camera (🔧 20, 33).

Enter the same e-mail address and nickname (alias) currently used by my Picturetown.

If the current nickname uses characters or symbols that are not available using the camera, enter a new nickname comprised of up to 16 alphanumeric characters. When a different nickname (alias) is registered with the camera, the nickname (alias) currently used by my Picturetown will be used to identify you in e-mail notification of picture upload sent to recipients.

When entering a password for my Picturetown using the Utility, enter the password currently used by my Picturetown.

4 Register the camera with the my Picturetown server.

If user information for my Picturetown is configured using the Utility, the specified user information and the camera's key information are sent to the my Picturetown server, over the Internet, once configuration is complete, finalizing registration.

If sender is configured using the camera, e-mail notification requesting user registration with my Picturetown is sent to the specified e-mail address after picture upload using Picture Mail or Picture Bank. Click the URL provided in the e-mail notification, enter the camera's key information, and register the camera with my Picturetown from the sign-up Web page (🔧 41). Once the camera has been registered with the my Picturetown server, an e-mail message confirming my Picturetown registration will be sent to the registered e-mail address.

Uploading Pictures to the my Pictown Server

Sending Picture Mail

Select pictures, specify recipients, and send Picture Mail.

When a wireless LAN access point is unavailable, Picture Mail can be queued and sent at a later time.

1 Press the button in shooting or playback mode.

If sender information has not been configured, enter your Email ID (e-mail address) and Nickname (alias) necessary for my Pictown user information ( 11, 33).



2 Press the rotary multi selector or to select the desired picture.



3 Specify recipients.


Rotate the rotary multi selector to move  (recipients) or  (recipient groups) to the selection area, and press the rotary multi selector  to select the recipient or group () , or  to cancel the selection.

When  is selected,  will be displayed for all recipients in a selected group.

To add a recipient or group, highlight **NEW**, press the  button, and enter the recipient's e-mail address (up to 64 recognized e-mail characters) or create a new group ( 34, 36). Mobile telephone e-mail addresses are not supported.

Once the new recipient or group has been created, monitor display will return to the queue mail screen. The first 16 characters of e-mail addresses are automatically used for corresponding aliases. Aliases can be edited later ( 34).

The number displayed at the top right of the monitor indicates the number of recipients specified for the current picture.



Selection area

4 Press the **OK** button to add the Picture Mail to the queue.

To specify recipients for different pictures, repeat steps 2 and 3 before applying the setting. Up to 30 pictures can be selected.

Press the **W** (📷) button before applying the setting to switch to thumbnail display to preview the pictures, for which recipients are specified, in the queue mail screen. Press the **T** (🔍) button to return to the queue mail screen.

5 Choose whether to upload pictures immediately.

Choose **Yes** and press the **OK** button to upload all the queued pictures. Be sure that a wireless LAN access point is available. Proceed to step 6.

Choose **No** and press the **OK** button to finalize picture selection and recipient specification in the queue. The camera will exit to the last shooting or playback mode selected (📷 45).



6 Connect to a wireless LAN and upload pictures.

See “Connecting to a Wireless LAN” (📷 49) for more information on connecting to a wireless LAN.

✓ Sending Picture Mail in the Queue

- When the **✉** button is pressed in shooting or playback mode, the queue mail screen shown in step 3 will be displayed (📷 44). Confirm the selected pictures and specified recipients, and press the **OK** button to send queued Picture Mail. To cancel the queue, cancel the recipients or groups specified for pictures and press the **OK** button.
- When a Picture Bank upload is initiated (📷 46, 47), queued Picture Mail will be sent at the same time. If you do not wish to upload queued Picture Mail with Picture Bank upload (📷 46, 47), press the **✉** button before initiating picture upload to cancel the queue in the queue mail screen.

📎 File Types Supported by Picture Mail

Still pictures, including those with voice memos attached, can be uploaded using the Picture Mail service. Movie and sound files cannot be uploaded.

📎 Picture Size for Picture Mail

If pictures are shot at image sizes greater than 1,600 × 1,200 pixels, their sizes will be reduced to 1,600 × 1,200 pixels when uploaded to the my Picturetown server.


📎 After Sending Picture Mail

When pictures are uploaded using Picture Mail, e-mail notification will be sent automatically to the specified recipients for the intended pictures. Recipients can click the URL included in e-mail notification to view and download the pictures stored on the my Picturetown server.

Using Picture Bank

Uploading All Pictures at Once


The camera automatically uploads pictures that have not yet been uploaded to the my Picturetown server whenever the AC adapter is connected to the camera. Charging begins once pictures have been uploaded.



1 Connect the power cable and AC adapter ①.

2 Confirm that the power-on lamp and the monitor are off.

If the power-on lamp is lit, press the power switch to turn off the camera. **Picture upload cannot be initiated by connecting the AC adapter when the camera is turned on.**



3 Connect the AC adapter to the camera's multi connector ②.

The multi connector should be fully inserted.

4 Plug the power cable into an outlet ③.

When the camera is turned on and the message, **Starting upload to Picture Bank**, is displayed, Picture Bank begins uploading pictures.

If sender setting has not been configured, enter your Email ID (e-mail address) and Nickname (alias) necessary for my Picturetown user information (11, 33).

See "Connecting to a Wireless LAN" (49) for more information on connecting to a wireless LAN.

Modifying the Automatic Picture Bank Upload Setting


Choose **On** (default setting) or **Off** from the camera's setup menu > **Wireless settings** (26) >

Picture Bank. If **Off** is selected, the battery begins charging immediately when the AC adapter is connected, and pictures are not uploaded.

Uploading Selected Pictures

- 1** Press the **MODE** button in playback mode and use the rotary multi selector to choose , and press the **OK** button.

If sender setting has not been configured, enter your Email ID (e-mail address) and Nickname (alias) necessary for my Picturetown user information (, 11, 27, 33).



If the previous transfer was not successfully completed over a wireless LAN connection, see "When the Transfer is Unsuccessful" (, 48) for more information.

- 2** Choose pictures.

Rotate the rotary multi selector, or press  or , to highlight a picture, and press  or  to select the desired picture (). Press  or  again to cancel a selection. Repeat this process to choose multiple pictures.

Up to 30 pictures can be selected.

Press the **T** () button to switch to full-frame playback; press the **W** () button to return to thumbnail display.


Press the **OK** button to finalize picture selection.



- 3** Upload pictures.

Choose **Yes** and press the **OK** button.

Choose **No** and press the **OK** button to return to the screen shown in step 2.




- 4** Connect to a wireless LAN and upload pictures.

See "Connecting to a Wireless LAN" (, 49) for more information on connecting to a wireless LAN.

When the Transfer is Unsuccessful

When transfer over a wireless LAN connection is unsuccessful, the next time you select  (Picture Bank) mode in the playback-mode selection menu and press the  button, the confirmation dialog shown at right will be displayed. If necessary, you can change the SSID from the confirmation dialog. Select **Yes** to resume the interrupted transfer. This confirmation dialog will not be displayed when upload of all pictures using Picture Bank is initiated by connecting the AC adapter ( 46).



File Types Supported by Picture Bank

Still pictures, including those with voice memos attached, and movie files can be uploaded using the Picture Bank service. Sound files cannot be uploaded.

Picture Bank Images

Pictures that have been uploaded to the my Picturetown server are referred to as "Picture Bank images" and can be recognized by  icon displayed with them in full-frame playback mode. Once the icon has been displayed with a picture, that picture cannot be uploaded to the server a second time using the automatic upload feature initiated when the AC adapter is connected to the camera. If pictures have been deleted from the server, and you would like to upload them again, choose  (Picture Bank) mode from the playback-mode selection menu ( 47) and select the desired pictures.

Connecting to a Wireless LAN

If the SSID selection screen is displayed when uploading pictures using the Picture Mail (📧 44) or Picture Bank (📧 46, 47) service, follow the procedures indicated below to select a wireless LAN network.

If the camera detects a network previously used to upload pictures using the Picture Mail service, or the Picture Bank service while the AC adapter is connected to the camera, picture upload will be initiated automatically.

1 Choose the desired SSID (network name) and press the **OK** button.

SSIDs (up to ten) are listed in order of signal strength (📶 52, 53). The icon to the left of each SSID is displayed in red when out of range.


The icon to the right of each SSID shows the status of the network profile registered to each SSID:

🏠 (home wireless LAN profile configured)

🌐 (public wireless LAN profile configured)

See "Public Wireless LAN" (📶 iv) for more information on countries in which public wireless LANs can be accessed by, and the wireless service providers that support connection of, this camera.




-- (no profile configured)



2 Connection to the wireless LAN is attempted.

If the selected SSID has not been configured with the camera, or you are connecting to it for the first time, the WEP key (📶 9) entry screen, or both the WEP key entry screen and the network user name and password (📶 10) entry screen, may be displayed. Enter the information required for connection (📶 31, 32).

The screens for connecting to the server, and for uploading pictures to the server, will be displayed. To cancel upload, press the **OK** button. When upload is complete, the screen indicating transfer completion will be displayed. After upload is complete, press the **OK** button*.



* Once upload of all pictures using the Picture Bank service, initiated by connecting the AC adapter, is complete, the camera turns off and the battery begins charging.


If user information has not been registered, e-mail notification requesting user registration with my Picturetown is sent to the specified e-mail address after picture upload. Register user information with my Picturetown. See "Registering with my Picturetown" (41) for more information.

✓ Connecting via a Wireless LAN

Be sure that you are in a location where connection of the camera to a wireless LAN is possible before attempting to upload pictures.

✍ Screen Displayed During Transfer

The screen shown at right is displayed during picture upload. The antenna icon in the top left corner of the screen indicates signal strength (5 levels). The icon changes to red when out of range. When signal strength is poor, be sure that you are not holding the camera in such a way that the antenna is obstructed, or remove any obstacles between the camera antenna and access point. Signal strength may be improved (52, 53).




✍ Wireless LAN LED

The wireless LAN LED, located on the side of the camera with the antenna, indicates connection status.

Blinks: The camera is searching for a network.

On: A connection has been established or data is being uploaded.

Off: The camera is not connected to a wireless LAN.



Wireless LAN LED

🔍 Checking SSID Contents

Pressing the **T** (?) button in the SSID selection screen displays the SSID (network name) and the profile type.



Viewing Pictures on the my Pictown Server

Use a computer's Web browser to access <http://mypictown.com/>, and enter the Email ID (e-mail address) and password registered with my Pictown to display the My Photos page.


From this page, you can upload and sort pictures, create and share albums, and create slide shows. Refer to help information contained in my Pictown for more information.

Deleting Picture Bank Images

The pictures stored in the internal memory or on the memory card, and taken on the specified date, that have already been uploaded to the my Pictown server can be deleted.

Register the camera and user information with my Pictown before deleting pictures from the internal memory or the memory card (41). When you receive the e-mail message confirming my Pictown registration, use a computer to be sure that the uploaded pictures have all been saved to my Pictown before deleting those pictures.

- 1 Press the **MODE** button in playback mode and use the rotary multi selector to choose **DATE** (list by date), and press the **OK** button.
The camera will enter list by date mode.
- 2 Choose the date and press the **OK** button.
The pictures will be displayed full frame in list by date mode.
- 3 Press the **MENU** button and use the rotary multi selector to choose **Delete** in list by date mode, and press the **OK** button.
- 4 Choose **Picture Bank images** and press the **OK** button.
The picture selection screen is displayed.
Rotate the rotary multi selector, or press **◀** or **▶**, to choose pictures and press **▲** to choose a desired picture (✔). Press **▼** to cancel a selection.
Press the **OK** button to finalize picture selection.
- 5 When a confirmation dialog is displayed, choose **Yes** and press the **OK** button.
The selected picture will be deleted.



Appendix

Error Messages

| Display | Problem | Solution |  |
|--|---|--|---|
|  Memory card is write protected. | Write-protect switch is in "lock" position. | Slide write-protect switch to "write" position. | 21 of the <i>User's Manual</i> |
|  Battery exhausted. Transfer terminated. | Battery exhausted during picture upload. | Use the AC Adapter EH-63, or charge the battery, turn the camera on again, and apply the last mode used for picture upload. | 16 of the <i>User's Manual</i> |
|  Password incorrect. | Entered password was not correct. | Enter the correct password. | 37 |
|  SSID not found | SSID was not detected. | <ul style="list-style-type: none">• Signal strength may be poor. Try the following and press the  button.<ul style="list-style-type: none">- Be sure that your hand is not obstructing the camera's antenna.- Change the camera's direction.- Move the camera closer to the access point.- Remove any obstacles between the camera's antenna and access point.• When Retry is displayed, select Retry and press the  button. | - |
|  Connection error. | Wireless connection to the SSID was terminated. | <p>Signal strength may be poor. Try the following and press the  button.</p> <ul style="list-style-type: none">- Be sure that your hand is not obstructing the camera's antenna.- Change the camera's direction.- Move the camera closer to the access point.- Remove any obstacles between the camera's antenna and access point. | - |

| Display | Problem | Solution |  |
|--|---|--|---|
|  ⓘ Connection error. | Connection to the server failed, or error occurred during picture upload. | <ul style="list-style-type: none"> Select Resume and press the OK button to attempt connection to the server again. Choose Select SSID and press the OK button to select SSID again. | 49 |
|  ⓘ User information incorrect. | Camera is not certified to connect to the wireless network. | Press the OK button and select SSID again. | 49 |
|  ⓘ Server is full. | my Pictown server is full. | Delete unnecessary pictures from the server. | - |
|  ⓘ Service not available. | Cannot use my Pictown network service. | Press the OK button and select SSID again. | 49 |
|  ⓘ Address incorrect. | An error occurred with Picture Mail recipient e-mail address. | Be sure that you have specified the recipient's e-mail address correctly. | 34 |
|  ⓘ Login failed. | Login error occurred. | <ul style="list-style-type: none"> Select Re-enter and press the OK button to configure Email ID and password again. | 28 |
| | | <ul style="list-style-type: none"> Select Select SSID and press the OK button to select SSID again. | 49 |

Troubleshooting

| Problem | Cause/Solution |  |
|---|--|---|
| The camera is not detected by the my Pictown Utility. | Confirm your camera's connection to the computer. | 15 |
| SSID is not displayed. | <ul style="list-style-type: none"> Configure a network profile. SSID is hidden. Signal strength may be poor. <ul style="list-style-type: none"> - Be sure that your hand is not obstructing the camera's antenna. - Change the camera's direction. - Move the camera closer to the access point. - Remove any obstacles between the camera's antenna and access point. | 17, 28 10 |

Index

A

- Alias 11
- Authentication 9, 18, 31

E

- Encryption 9, 18
- Encryption key 9, 31

G

- Gateway 10, 18, 32

H

- Home wireless LAN 8

I

- IP address 10, 18, 32

K

- Key index 9
- Key information 11

M

- MAC address 10
- my Pictoretown 4, 41, 51
- my Pictoretown Utility (Utility) 7, 13, 15

N

- Network name (SSID) 9, 17, 30, 49, 50
- Network profile 9, 17, 28

P

- Password 12, 23, 37
- Picture Bank 5, 46
- Picture Mail 5, 44
- PIN method 40
- Primary DNS 18, 32
- Public wireless LAN 8

- Push Button Configuration method 39

R

- Recipient 12, 22, 34
- Recipient group 12, 22, 36
- Reset 24, 38

S

- Secondary DNS 18, 32
- SSID (network name) 9, 17, 30, 49, 50
- Subnet mask 10, 18, 32

T

- Text entry 27

U

- User registration 41
- Utility (my Pictoretown Utility) 7, 13, 15

W

- Wi-Fi Protected Setup 7
- Wireless settings 13, 26
- WPS 7



A series of horizontal dashed lines spanning the width of the page, intended for handwriting practice. There are 15 lines in total, starting from the top right and extending to the bottom left.

Nikon

No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

NIKON CORPORATION

Fuji Bldg., 2-3 Marunouchi 3-chome,
Chiyoda-ku, Tokyo 100-8331, Japan

© 2008 Nikon Corporation



Printed in Europe
YP8H01(11)
6MMA8611-01